

Key message

- The design of scaffold should take account of installation restrictions and make sure components are selected that suitable for safe installation by those undertaking the works.
- Supervisors in charge of works should be provided with and briefed on the Work Package Plan and Task Briefing contents and ideally involved in their development.
- Specific risk controls detailed in the Work Package Plan should be incorporated into the Task Briefing Sheet to make sure that the correct level of detail is delivered through briefing to those undertaking the works.
- Principal Contractors to review their assurance procedures and processes to assure that Contractors/Sub-Contractors are working in accordance with defined methodology and designs/specifications.

Part of our group
of Safety Bulletins

**Safety
Alert**

**Safety
Bulletin**

**Safety
Advice**

**Shared
Learning**